


TYPE 3




WARNING
 All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Gasket Kit
59

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016386	Screw	24.	530019264	Seal-Crankcase	47.	530012500	Cylinder
2.	530058573	Assy-Shroud/H'shield	25.	530032125	Bearing-Inner	48.	530015953	Screw
3.	530071486	O-Ring-C'case (kit)	26.	530015934	Screw	49.	530071486	Gasket-Muffler (kit)
4.	530012571	Assy-Crankshaft	27.	530071486	Seal-Cylinder (kit)	50.	530071682	Kit-Muffler (incl. # 49,51,52,53)
5.	530071681	Assy-C'case-C/shaft (Incl. #4,6 & 22-25)	28.	530071785	Kit-Piston/Rod Assy. (Incl. 29 & 30)	51.	530016338	Bolt-Muffler
6.	530015941	Ring-Retainer-C'shaft	29.	530069945	Assy-Connecting Rod	52.	530071544	Kit-Spark Arrestor
7.	530071487	Assy-Flywheel	30.	530071833	Kit-Piston (Incl. 31 & 32)	53.	530015241	Screw
8.	530015828	Washer-Flat	31.	530015162	Retainer-Piston Pin	54.	530095992	Assy-Pick-up
9.	530055729	Spacer-Flywheel	32.	530055120	Ring-Piston	55.	530069247	Kit-Fuel Line(small)
10.	530015496	Screw	33.	530071486	Gasket-Carb. Adapt.(kit)	56.	530069216	Kit-Fuel Line(large)
11.	530055681	Plate-Baffle	34.	530057634	Adapter-Carburetor	57.	530023877	Fitting-Fuel Line
12.	530015882	Screw	35.	530016309	Screw	58.	530016103	Clip-Retainer
13.	530069353	Kit-Starter Pulley (Incl.# 12)	36.	530071633	Kit-Carburetor Ass'y. (C1U-W13A)	59.	530071486	Kit-Gasket (Incl. #3,27,33,44,49)
14.	530055762	Assy-Fan Housing	37.	530071718	Kit-Choke Lever			
15.	530027569	Handle-Starter	38.	530055680	Air Box			
16.	530069232	Kit-Rope	39.	530016429	Screw			
17.	530019182	Grommet-Ignition Module	40.	530047932	Air Filter Foam			
18.	530016386	Screw-(f/hsg to shrd)	41.	530055679	Air Filter Cover			
19.	530042085	Spring-Starter	42.	530015957	Screw			
20.	530016357	Screw	43.	530015158	Washer			
21.	530054137	Ignition Module	44.	530071486	Gasket-Carburetor(kit)	530164003		Operator Manual
22.	530012510	Assy-Crankcase	45.	530058756	Assy-Throttle Cable			
23.	530055728	Bearing-Outer	46.	952030249	Spark Plug(RCJ-6Y)			

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
 ● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

TYPE 4



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016386	Screw	24.	530019264	Seal-Crankcase	47.	530012500	Cylinder
2.	530058573	Assy-Shroud/H'shield	25.	530032125	Bearing-Inner	48.	530015953	Screw
3.	530071486	O-Ring-C'case (kit)	26.	530015934	Screw	49.	530071486	Gasket-Muffler (kit)
4.	530012571	Assy-Crankshaft	27.	530071486	Seal-Cylinder (kit)	50.	530071682	Kit-Muffler (Incl. # 49,51,52,53)
5.	530071681	Assy-C/case-C/shaft (Incl. #4,6 & 22-25)	28.	530071785	Kit-Piston/Rod Assy. (Incl. 29 & 30)	51.	530016338	Bolt-Muffler
6.	530015941	Ring-Retainer-C'shaft	29.	530069945	Assy-Connecting Rod	52.	530071544	Kit-Spark Arrestor
7.	530071487	Assy-Flywheel	30.	530071833	Kit-Piston (Incl. 31 & 32)	53.	530015241	Screw
8.	530015828	Washer-Flat	31.	530015162	Retainer-Piston Pin	54.	530095992	Assy-Pick-up
9.	530055729	Spacer-Flywheel	32.	530055120	Ring-Piston	55.	530069247	Kit-Fuel Line(small)
10.	530015496	Screw	33.	530071486	Gasket-Carb. Adapt. (kit)	56.	530069216	Kit-Fuel Line(large)
11.	530055681	Plate-Baffle	34.	530057634	Adapter-Carburetor	57.	530023877	Fitting-Fuel Line
12.	530015882	Screw	35.	530016309	Screw	58.	530016103	Clip-Retainer
13.	530069353	Kit-Starter Pulley (Incl.# 12)	36.	530071633	Kit-Carburetor Ass'y. (C1U-W13A)	59.	530071486	Kit-Gasket (Incl. #3,27,33,44,49)
14.	545037404	Assy-Fan Housing	37.	530071718	Kit-Choke Lever			
15.	530027569	Handle-Starter	38.	530055680	Air Box			
16.	530069232	Kit-Rope	39.	530016429	Screw			
17.	530019182	Grommet-Ignition Module	40.	530047932	Air Filter Foam			
18.	530016386	Screw-(f/hsg to shrd)	41.	530055679	Air Filter Cover			
19.	530042085	Spring-Starter	42.	530015957	Screw			
20.	530016357	Screw	43.	530015158	Washer			
21.	530054137	Ignition Module	44.	530071486	Gasket-Carburetor(kit)			
22.	530012510	Assy-Crankcase	45.	530058756	Assy-Throttle Cable	↖	545186732	Operator Manual
23.	530055728	Bearing-Outer	46.	952030249	Spark Plug(RCJ-6Y)			


↖ = NEW PART NUMBER FOR THIS IPL ★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

Note: Illustration may differ from actual model due to design changes

TYPE 1



WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054133	Assy-Leadwire/Switch (Incl.#2)	18.	530029948	Seal-Blade (Felt)
2.	530029954	Switch-Ignition	19.	530403229	Assy-Blade 22"
3.	530071656	Assy-Rear Handle & Tank	20.	530029946	Spring
4.	545024810	Washer-Clutch (Kit)	21.	530014871	Assy-Fuel Cap
5.	545024810	Assy-Clutch (Kit)	22.	530016406	Screw
6.	545024810	Drum-Clutch (Kit)	23.	530053900	Lockout-Throttle
7.	530096102	Assy-Gear Box (incl.# 9-11)	24.	530015934	Screw
8.	530015886	Screw	25.	530038305	Cover-Handle
9.	530016013	Bearing-Gear	26.	530015940	Screw
10.	530096009	Assy-Pinion	27.	530015775	Screw
11.	530015805	Screw	28.	530029958	Lever-Trigger
12.	530032121	Bushing-Blade	29.	530036123	Spring-Trigger
13.	530036046	Plate-Isolator	30.	530053884	Trigger
14.	530015849	Screw	31.	530015955	Screw
15.	530015934	Screw	32.	530094992	Handle-Front
16.	530029916	Cover-Gear Box Plate			
17.	530071690	Kit-Drive Gear Ass'y. (Incl. #12)			

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

TYPE 2

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054133	Assy-Leadwire/Switch (Incl.#2)	19.	530071690	Kit-Drive Gear Ass'y. (Incl. #12)
2.	530029954	Switch-Ignition	20.	530029948	Seal-Blade (Felt)
3.	530071656	Assy-Rear Handle & Tank	21.	530403229	Assy-Blade 22"
4.	545024810	Washer-Clutch (Kit)	22.	530016284	Nut
5.	545024810	Assy-Clutch (Kit)	23.	530029946	Spring
6.	545024810	Drum-Clutch (Kit)	24.	530014871	Assy-Fuel Cap
7.	530071931	Assy-Gear Box (incl.# 9-11,13,17,22)	25.	530016406	Screw
8.	530015886	Screw	26.	530053900	Lockout-Throttle
9.	530016013	Bearing-Gear	27.	530015934	Screw
10.	530096009	Assy-Pinion	28.	530038305	Cover-Handle
11.	530015805	Screw	29.	530015940	Screw
12.	530032121	Bushing-Blade	30.	530015775	Screw
13.	530015940	Screw	31.	530029958	Lever-Trigger
14.	530036046	Plate-Isolator	32.	530036123	Spring-Trigger
15.	530015849	Screw	33.	530053884	Trigger
16.	530015934	Screw	34.	530094992	Handle-Front
17.	530016472	Screw	35.	530015955	Screw
18.	530029916	Cover-Gear Box Plate			

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

TYPE 3

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054133	Assy-Leadwire/Switch (Incl.#2)	19.	530071690	Kit-Drive Gear Ass'y. (Incl. #12)
2.	530029954	Switch-Ignition	20.	530029948	Seal-Blade (Felt)
3.	530071656	Assy-Rear Handle & Tank	21.	530403229	Assy-Blade 22"
4.	530015828	Washer-Clutch	22.	545009101	Nut
5.	530014396	Kit-Clutch Assy.	23.	530029946	Spring
6.	530056069	Assy-Drum	24.	530014871	Assy-Fuel Cap
7.	530071931	Assy-Gear Box (incl.# 9-11,13,17,22)	25.	530016406	Screw
8.	530015886	Screw	26.	530053900	Lockout-Throttle
9.	530016013	Bearing-Gear	27.	530015934	Screw
10.	530096009	Assy-Pinion	28.	545008001	Kit-Handle Cover
11.	530015805	Screw	29.	530015940	Screw
12.	530032121	Bushing-Blade	30.	530015775	Screw
13.	530015940	Screw	31.	530057818	Lever-Trigger
14.	530036046	Plate-Isolator	32.	530036123	Spring-Trigger
15.	530015849	Screw	33.	530053884	Trigger
16.	530015934	Screw	34.	530094992	Handle-Front
17.	530016472	Screw	35.	530015955	Screw
18.	530029916	Cover-Gear Box Plate			

✓ = NEW PART NUMBER FOR THIS IPL ★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

TYPE 4

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054133	Assy-Leadwire/Switch (Incl.#2)	19.	530071690	Kit-Drive Gear Ass'y. (Incl. #12)
2.	530029954	Switch-Ignition	20.	530029948	Seal-Blade (Felt)
3.	530071656	Assy-Rear Handle & Tank	21.	530403229	Assy-Blade 22"
4.	530015611	Washer-Clutch	22.	545009101	Nut
5.	530071803	Kit-Clutch Assy.	23.	530029946	Spring
6.	530150583	Assy-Drum	24.	530014871	Assy-Fuel Cap
7.	530071931	Assy-Gear Box (incl.# 9-11,13,17,22)	25.	530016406	Screw
8.	530015886	Screw	26.	530053900	Lockout-Throttle
9.	530016013	Bearing-Gear	27.	530015934	Screw
10.	530096009	Assy-Pinion	28.	545008001	Kit-Handle Cover
11.	530015805	Screw	29.	530015940	Screw
12.	530032121	Bushing-Blade	30.	530015775	Screw
13.	530015940	Screw	31.	530057818	Lever-Trigger
14.	530036046	Plate-Isolator	32.	530036123	Spring-Trigger
15.	530015849	Screw	33.	530053884	Trigger
16.	530015934	Screw	34.	530094992	Handle-Front
17.	530016472	Screw	35.	530015955	Screw
18.	530029916	Cover-Gear Box Plate			

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.